Freezer 13

Installation Manual

For further information, please consult www.arctic.ac

DE Deutsches Handbuch online verfügbar.
FR Le manuel en français est disponible en ligne.
ES Mañual êñ êspa ol dispoñiblê êñ líñêa
PT Manual em Portugu s disponível online.
SE Svensk manual tillgänglig online.
CZ N vod v češtině dostupný online.
HU A magyar kézikönyv az interneten is elérhető.
PL Polski podręcznik dostępny na stronie internetowej
NL Nederlandstalige handleiding is online beschikbaar.

Accessories

Intel:

Screws (M3) x 2

Push pins x 4

Push pins x 4

Mounting plate x 1



AMD:

Screws (M3) x 2

Lugs x 2



Preparation





For Intel Sockets

1



2



3



4



5



6



7



8



For AMD Sockets



Limits of Warranty

Warranty coverage does not include the following:

- A faulty product that leads to harm or damage to other products
- Damage of product as a result of other product components
- Incorrect method of operation or use of product not for intended use
- Any form of alteration to original product
- Inability to install the product as a result of incompatibility with other components

Thermal Compound

The thermal compound is already pre-applied to the heatsink. If the cooler has to be installed a second time, we highly recommend using the ARCTIC MX-2 or the ARCTC MX-4 from ARCTIC. Only our compound guarantees optimal performance in combination with the surface of our heatsinks.

ARCTIC Switzerland
Huobstrasse 4
8808, Pfäffikon, Switzerland
www.arctic.ac

Copyright©
2010 ARCTIC Switzerland. All Rights Reserved.
No part of this manual including the products described in it, may be reproduced, transmitted, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ARCTIC Switzerland. In no event shall ARCTIC its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.